

Read Me First!

Radar Display Unit Software Update

Your display unit must have the latest software version to work with radar and the RIM 200. Depending on when you bought your display, it may require a software update. To avoid delays in setting up your radar system, your radar package includes an MMC or SD memory card with a software upgrade.

2007 Model Units

You WILL NOT need to update the software version in 2007-model units which include: X510C, X515C DF sonars; LMS-520C, LMS-522C iGPS, LMS-525C DF, LMS-527C DF iGPS, LCX-27C, LCX-28C HD, LCX-37C, LCX-38C HD, LCX-112C, LCX-113C HD sonar/GPS combos; and GlobalMap® 5200C, GlobalMap® 5300C iGPS, GlobalMap® 7200C, GlobalMap® 7300C HD, GlobalMap® 8200C, GlobalMap® 8300C HD, GlobalMap® 9200C, GlobalMap® 9300C HD GPS units.

2006 Model Units

If you are using a 2006-model unit, access the software information screen to make sure its software version is 1.7 or greater. If the version of software in your unit is less than 1.7 you will need to install the software update contained on the card that came with your RIM 200. You should check the software version for the following units to ensure they will work with the RIM 200: LCX-25C, LCX-26C HD, LCX-110C, LCX-111C HD sonar/GPS combos; and GlobalMap® 6500C, GlobalMap® 6600C HD, GlobalMap® 7500C, GlobalMap® 7600C HD GPS units.

Checking Software Version

1. With the display unit turned on, press **MENU** twice, use the arrow keys to highlight **SYSTEM SETUP** and press **ENTER**.
2. Use the arrow keys to select **SOFTWARE INFORMATION** and press **ENTER**. The software information screen will appear. If the version of software listed on the software information screen is less than 1.7 you will need to install the software update contained on the card that came with your RIM 200.

Installing Software Update

1. With the display unit turned off, install the MMC card that contains the radar software update.
2. Turn on the unit and the update will install automatically.
3. When the update is finished, the unit will power up normally. After the update is complete, remove the update MMC from the card slot.

The update program will be erased automatically when the process is complete. You can now use this card to record sonar logs or GPS data.

NOTE:

Lowrance continues to regularly develop display enhancements and new radar features. ***We strongly recommend that you periodically check our web site for the latest free radar software updates.***

If you or a friend has Internet access, log-on to www.lowrance.com, browse to our Software page and look for the Product Updates link. Keep track of updates the easy way by subscribing to our free e-mail software release notices. Just look for the link at the bottom of our Product Software Upgrades web page.

If you lack Internet access, call your dealer or Lowrance Customer Service. To obtain service in the U.S. call 1-800-324-1356 Monday through Friday from 8 a.m.-5 p.m. Central Standard Time. If you need service in Canada call 1-800-661-3983 or 1-905-629-1614 Monday through Friday from 8 a.m.-5 p.m. Eastern Standard Time.

Customers trying to reach us from outside the U.S. or Canada should contact the dealer in the country where they purchased the unit. To locate a dealer near you visit the Lowrance Electronics Inc. web site at www.lowrance.com and look for the Dealer Locator link.