

# Read Me First!

## Radar Display Unit Software Update

Your display unit must have software version 1.3.0 or later to work with radar. Depending on when you bought your display, it may require a software update. To avoid delays in setting up your radar system, your radar package includes an MMC or SD memory card with a basic software upgrade.

### Installing Software Update

1. With the display unit turned off, install the MMC card that contains the radar software update.
2. Turn on the unit and the update will install automatically.
3. When the update is finished, the unit will power up normally. After the update is complete, remove the update MMC from the card slot.

The update program will be erased automatically when the process is complete. You can now use this card to record sonar logs or GPS data.

### NOTE:

Lowrance continues to regularly develop display enhancements and new radar features. ***We strongly recommend that you periodically check our web site for the latest free radar software updates.***

If you or a friend has Internet access, log-on to [www.lowrance.com](http://www.lowrance.com), browse to our Software page and look for the Product Updates link. Keep track of updates the easy way by subscribing to our free e-mail software release notices. Just look for the link at the bottom of our Product Software Upgrades web page.

If you lack Internet access, call your dealer or Lowrance Customer Service. To obtain service in the U.S. call 1-800-324-1356 Monday through Friday from 8 a.m.-5 p.m. Central Standard Time. If you need service in Canada call 1-800-661-3983 or 1-905-629-1614 Monday through Friday from 8 a.m.-5 p.m. Eastern Standard Time.

Customers trying to reach us from outside the U.S. or Canada should contact the dealer in the country where they purchased the unit. To locate a dealer near you visit the Lowrance Electronics Inc. web site at [www.lowrance.com](http://www.lowrance.com) and look for the Dealer Locator link.